

FISHING ROD HOLDER

P/N 610-00003-01

INSTALLATION INSTRUCTIONS



Tools Required

#2 Phillips Screwdriver

Manufactured by:
FLOE INTERNATIONAL, INC.
48473 State Hwy. 65
McGregor, MN 55760
www.floeintl.com

INSTALLATION INSTRUCTIONS

1. Remove bumper top cap.



2. Insert screws through designated holes on rod holder.



3. Place tabs on screws.
Do not tighten.



4. Slide tabs into track on bumper.



5. Once in position, tighten with #2 Phillips Screwdriver.



6. Replace bumper cap.