



Fig. 1

## **FLOATING DOCK BUMPER EDGING INSTALLATION INSTRUCTIONS P/N 510-00310-00**

1. Cut bumper edging to desired length and place on dock section.
2. Drill holes for rivets using a #9 drill (.196 dia.). See Fig. 1 below for proper spacing.
3. Rivet bumper edging to dock section using the 3/16" x 1 1/4" LF rivets provided. Rivets should be placed a min. of 3/8" from inside edge of edging for safety reasons.

Note:

Optional FLOE corner bumpers are recommended on all outside corners (P/N 510-04100-00)

This kit contains:

- (2) 10' long dock bumper edging sections (P/N 010-00800-00)
- (40) 3/16" x 1 1/4" LF rivets (P/N 001-06800-00)

Tools Required:

- Cordless Drill
- #9 Drill Bit
- Rivet Gun

**WARNING (CORDED DRILLS): TO AVOID ELECTRIC SHOCK DURING DRILLING. USE OF A GROUND FAULT INTERRUPT CIRCUIT IS REQUIRED. FAILURE TO FOLLOW THIS WARNING MAY RESULT IN DEATH BY ELECTROCUTION. DOCK SHOULD BE REMOVED FROM LAKE PRIOR TO DRILLING TO MINIMIZE RISK.**

Manufactured by:  
Floe International Inc.  
48473 State Hwy. 65  
McGregor, MN 55760  
www.floeintl.com