



4500# VSD 24V DRIVE TRAIN
EXPLODED VIEW
P/N 511-45014-00



4500# VSD 24V DRIVE TRAIN
EXPLODED VIEW
P/N 511-45014-00



4500# VSD 24V DRIVE TRAIN

EXPLODED VIEW

P/N 511-45014-00

NO.	PART NUMBER	QTY	DESCRIPTION
1	001-41584-00	4	RIVET-NUT, 3/8-16
2	001-70105-00	4	HHCS, 3/8-16 x 1" ss
3	001-71013-00	8	FLAT WASHER, 1/4" ss
4	001-71055-00	4	LOCK WASHER, # 6 SPLIT ss
5	001-71067-00	4	LOCK WASHER, 3/8" SPLIT ss
6	001-71360-00	4	SMS, # 6-32 x 3/8" ss
7	001-73094-00	8	HHSMS, # 10 x 3/8" ss
8	001-73753-00	4	BHCS, 1/4-20 x 5/8" ss
9	001-73895-00	4	FHCS, 1/4-28 x 1/2" ss
10	001-75001-00	4	NUT, NYLOCK 1/4-20 ALUMINUM
11	002-04316-00	1	COUPLER HOUSING - 24V VSD
12	003-02301-00	1	GROMMET - 1 1/16" x 3/4" ID
13	007-03907-00	1	24V DC GEARMOTOR (20:1)
14	007-03910-00	1	24V DC ELECTRIC BRAKE
15	007-03940-00	2	SOLENOID - 24V GEARMOTOR
16	007-05056-00	1	WIRED REMOTE
17	007-05071-00	1	5A CIRCUIT BREAKER
18	007-05094-00	1	COVER PLUG
19	007-05096-00	1	3/16" SQUARE x 1 1/4" KEY
20	007-05170-00	1	LOVEJOY COUPLER - 3/4" BORE
21	007-05171-00	1	10A CIRCUIT BREAKER
22	007-05172-00	1	40A AUTO RESET CIRCUIT BREAKER
23	007-05178-00	1	DRIVE TRAIN CHASSIS
24	007-05179-00	1	DRIVE TRAIN COVER
25	007-05180-00	1	24V BATTERY POWER CABLE (63")
26	007-05181-00	1	24V BATTERY INTERCONNECT CABLE (32")
27	007-05182-00	2	VSD SOLENOID STRAP (END)
28	007-05183-00	1	VSD SOLENOID STRAP (SIDE)
29	007-05184-00	1	VSD SOLENOID STRAP (SIDE 3 HOLE)
30	111-00304-00	1	WIRE HARNESS - 4500 VSD 24V

