



Replacement Axle Guide (2005 and older VersaMax RT ramp and tilt trailers) ***for Versa Max and Pro 100 Snow Trailers***



Replacement Axle Guide for Versa Max and Pro 100 Snow Trailers



2005 and older Versa Max RT ramp and tilt trailers

Requires welding on new mounting brackets to the trailer frame by a certified aluminum welder.

Important: 8" and 10" wheels no longer fit on the current Auto Flex Knott axles. The trailing arm does not have a dog leg like the original axle. Replacing the axle on a trailer with 8" or 10" wheels will require spacer blocks and 13" wheels.

(Tire ST175/80 R13, Load Range D, Bolt Circle 5 on 4 ½)

1. Choose axle accordingly

- 10', 12', 14', and 16' idler axle (no brake)
3000# idler axle, 3.5" rise, 10 degree down
P/N 550-07283-00
- 12', 14', and 16' electric brake axle
3000# electric brake axle, 3.5" rise, 10 degree down
P/N 550-07294-00
- 20', 22', and 28' electric brake trailers
3000# electric brake axle, 1" rise, 10 degree down
P/N 550-07285-00
- 12' Enclosure
3000# idler axle (no brake)
P/N 550-07283-00

2. Weld on brackets *FLOE no longer carries the old style slide mounts. Choose the appropriate weld-on version below. The new mounts should be welded to your trailer frame by a certified aluminum welder.

10' and 12' trailers

P/N 002-01320-00

14'-22' trailers

P/N 002-01323-00

*** NEED TWO PER AXLE**

3. Axle Mounting Kit

P/N 551-27510-00

***One kit per axle**

4. Spacer block (if needed)

Going from 8" or 10" wheels to 13" wheels require 2" spacer block

P/N 551-28700-00 (sold in pair)
