



**FLOE QUICK ATTACH SECTIONAL  
DOCK BENCH/LADDER BRACKET KIT**  
ASSEMBLY INSTRUCTIONS  
KIT P/N 510-02570-00



**\*DOCK, LEGS, BENCH, AND LADDER NOT INCLUDED**


NOTE: TWO 9/16" WRENCHES MAY BE  
REQUIRED, DEPENDING ON THE STYLE OF THE  
QUICK ATTACH ACCESSORY BRACKET

**TOOLS REQUIRED**

- (2) 9/16" SOCKETS/WRENCHES
- TORQUE WRENCH




**BILL OF MATERIALS/EXPLODED VIEW**

P/N 510-02570-00	KIT, QA SECTIONAL LADDER/BENCH		
NUMBER	PART NUMBER	DESCRIPTION	QTY
1	001-02570-01	FASTENERS, QUICK ATT. LADDER/BENCH	1
1A	001-70105-00	HHCS, 3/8-16 X 1" 18-8 SS	2
1B	001-70114-00	HHCS, 3/8-16 X 2-3/4" 18-8 SS	4
1C	001-76071-00	NUT, NYLOCK 3/8-16 ALUM.	4
2	002-00150-01	BRACKET, QA SCTN'L ACCY. – 2"	2



## LADDER ATTACHMENT

FIRST, DETERMINE WHERE THE LADDER WILL BE INSTALLED ON THE DOCK SYSTEM. INSERT (2) 3/8" X 2-3/4" BOLTS INTO EACH BRACKET AND INTO THE CORRESPONDING HOLES ON THE LADDER (FIGURE 1.1). PLACE A 3/8" NYLOCK NUT ONTO EACH BOLT (FIGURE 1.2). TORQUE TO 30 FT-LB (FIGURE 1.3).



START A 3/8" X 1" BOLT INTO THE BOTTOM OF EACH BRACKET. DO NOT TIGHTEN (FIGURE 1.4). PLACE THE BRACKETS INTO THE DOCK SIDE IN THE DESIRED LOCATION (FIGURE 1.5). TORQUE BOLTS TO **6 FT-LB MAXIMUM** (FIGURE 1.6).

FIGURE 1.4

2X

INSTALL INTO  
BOTTOM  
OF BRACKET

3/8" X 1" BOLT






FIGURE 1.5




TORQUE TO  
6 FT-LB MAX

FIGURE 1.6



## BENCH ATTACHMENT

FIRST, DETERMINE WHERE THE BENCH WILL BE INSTALLED ON THE DOCK SYSTEM. INSERT (2) 3/8" X 2-3/4" BOLTS INTO EACH BRACKET AND INTO THE CORRESPONDING HOLES ON THE BENCH (FIGURE 1.1). PLACE A 3/8" NYLOCK NUT ONTO EACH BOLT (FIGURE 1.2). TORQUE TO 25 FT-LB (FIGURE 1.3).





START A 3/8" X 1" BOLT INTO THE BOTTOM OF EACH BRACKET. DO NOT TIGHTEN (FIGURE 1.4). PLACE THE BRACKETS INTO THE DOCK SIDE IN THE DESIRED LOCATION (FIGURE 1.5). TORQUE BOLTS TO **6 FT-LB MAXIMUM** (FIGURE 1.6).

FIGURE 1.4

2X

INSTALL INTO  
BOTTOM OF  
BRACKET

3/8" X 1" BOLT



**NOTES**

