


# FLOE ROLL-IN SEAWALL CONNECTION KIT

## ASSEMBLY INSTRUCTIONS

KIT P/N 510-35100-00




**\*DOCK SECTION & WHEEL KIT NOT INCLUDED**

### TOOLS REQUIRED

- 9/16" SOCKET/WRENCH
- 1/4" DRILL BIT
- CORDLESS DRILL
- TAPE MEASURE



# BILL OF MATERIALS

P/N 510-35100-00		SEAWALL ATTACHMENT KIT, ROLL-IN DOCKS	
NUMBER	PART NUMBER	DESCRIPTION	QTY
1	001-74527-00	SCREW, LAG – 3/8" X 4" SS 18-8	4
2	110-00082-00	WELD'T, SEAWALL ATTACH. BRACKET	2



# ASSEMBLY

FIRST, DETERMINE WHERE THE ATTACHMENT BRACKETS SHOULD BE ON THE SEAWALL. MEASURE BETWEEN THE SIDE FRAME TUBES, INSIDE TO INSIDE TO DETERMINE PROPER SPACING FOR OTHER DOCKS. FOR EXAMPLE, BRACKETS INSTALLED FOR A 4' DOCK WILL BE PLACED APPROXIMATELY 46" APART (FIGURE 1.1). PLACE THE BRACKETS 7-1/4" FROM THE TOP OF THE SEAWALL (FIGURE 1.2).



FIND THE CENTER OF THE SEAWALL AND TRANSFER MEASUREMENT TAKEN FROM DOCK (FIGURE 1.3) ONCE THE BRACKETS ARE PLACED, DRILL (2) PILOT HOLES PER BRACKET, THEN ATTACH TO THE SEAWALL USING (2) 3/8" X 4" LAG SCREWS (FIGURE 1.4). PLACE THE DOCK SECTION INTO THE BRACKETS INTO THE INNERMOST SLOT IN THE BRACKET (FIGURE 1.5).

